



1. Install / un-install the ear pads

You will have 16x spare sticky Velcro disks provided in the Urbanize box.

1. Take 4x Velcro disks and attach the Velcro side of them to the outside of each ear pad as shown in diagram 1A.
2. Pass the strap through the loop in the inside of the ear pad as shown in diagram 1B.
3. Ensure the pad is positioned between the helmet shell and the fit system as shown in diagram 1C.



1. Install / un-install the ear pads

4. Align the pad on the inside of the helmet and stick the pads to the shell as shown in diagram 1D.

The ear pads should be firmly in place when installed.

5. To un-install, simply pull the ear-pad away to detach the Velcro and un-thread the strap from the loop on the ear-pad. Leave the adhesive Velcro pads stuck to the helmet shell ready for the next time you want to install the ear pads.

1D)



2. Install / un-install the front vent pad

You can reduce the airflow going into your helmet by blocking up the front vent, this will help to keep your head warm during cold winter commutes.

1. To do this, simply align and push the pad into the front vent from the inside of the helmet as shown in diagram 2A.

2. To remove the front vent pad, simply pull it out of the helmet by pulling the tab here.

2A)

