








LAZER

VeloVox

POCKET GUIDE

English

Cardo CONNECT APP








Cardo Connect App for Lazer






Table of Contents
4-5 Getting Started
6 Cardo Connect App
7 General
8 Music
9 Phone Call
10 Cellular Intercom
11 Factory Reset & Reboot
Advanced Features
12 Shimano Connectivity
13 Default settings
Customizing Shimano Connectivity

Getting Started
















Cardo Connect App



Download







R Register





Choose Language





(<1) Update Software



General



(◀+) Volume Up





◀-) Volume Down







(Voice Assistant









Music On R Off R Next Track R Previous Track R

Phone Call



Answer









R



►) End Call






Cellular Intercom



Intercom grouping



Intercom ON/OFF





(A) Mute Microphone





Unmute Microphone





Factory Reset & Reboot



Factory Reset











Reset audio unit





Reset communication unit

Advanced Features

Shimano Connectivity






1) Update your Di2 firmware. 2) Set button(s) on Shimano Di2 shifters to a D-Fly channel with the Shimano E-Tube App. 3) Press any button on shifter for pairing.



SHIMANO EBIKE

1) Update your firmware. 2) Set button(s) on Shimano EBIKE systems to a D-Fly channel with the Shimano E-Tube App. 3) Switch on the bike for pairing.






- 1. Do not pair when other bike is around
- 2. Put your bike not further than 1 m



Default settings



Overview of default settings



Customizing Shimano Connectivity



Open Settings menu



(29) Open Shimano Connectivity



(P) Change commands



www.lazersport.com



Reach out and follow us:

- @Lazersport
- # LazerHelmets
- info@lazersport.com

 info



Cardosystems.com/update Cardosystems.com/support